


SHOUT ts/SHOUT tw QUICK START GUIDE


DEVICE DESCRIPTION: The SHOUT tw comprises a touchscreen, a Power/Back button, an LED Status Display, a guarded Emergency button, and a USB port.

❑ **IMPORTANT:** The SHOUT tw must have a full view of the sky during transmission.



SHOUT ts/SHOUT tw QUICK START GUIDE

DEVICE STATUS SYMBOLS: Device status symbols are displayed along the top three lines of all screens. Some symbols do not appear until an event is initiated, such as sending or receiving a message.




911 EMERGENCY

- ❑ Activate 911 Emergency: Press the **911 Emergency** button ● on the device. The Status bar turns red and the status LED turns solid green. An alert is immediately sent to a designated monitoring center(s).





- ❑ Cancel 911 Emergency: Navigate to the **Tracking Menu** and select **Cancel 911** ☒.

NOTE: The Cancellation message is queued in the Outbox to be transmitted, and the Emergency mode ends immediately. Turning the SHOUT ts off does not cancel the Emergency mode. You **MUST** select the **Cancel 911** ☒ option to cancel the emergency.







POWER ON/OFF DEVICE

- ❑ Press the **Power** button  for two seconds to turn on device.
- ❑ Press the **Power** button  for two seconds to turn off device.
 A Power-down Screen appears.
 - Press **Turn Off** to turn off the SHOUT tw.
 - Press **Lock** to go back to the power-up screen, or press **Cancel** to return to the previous screen





MESSAGES

❑ Check Messages

1. Select **Texting**  from the Home screen.
2. Select **Inbox**  from the Texting screen.
 - Read messages have a white opened envelope symbol  next to them.
 - Unread messages have a green closed envelope symbol.
 - A closed envelope symbol  appears at the top of the screen when an unread message(s) is in the Inbox.





❑ Compose Message

1. Select Texting  from the Home screen.
2. Select Compose  from the Texting screen.

MESSAGES (continued)

Sent Messages

1. Select Texting  from the Home screen, then select Sent  from the Texting screen . This displays a list of messages that were successfully sent to the NOC. A message can be resent, forwarded, or deleted.

CHARGING BATTERY

- Fully charge the SHOUT tw before use. The SHOUT tw must be kept in environments between 0°C (32°F) and 45°C (113°F) when charging.
- The SHOUT tw can be charged with the supplied AC wall adapter or connect to a standard USB device.
NOTE: the battery symbol turns red when the remaining power is less than 20%. A warning message appears when the remaining power is less than 10%.



WARNING!

All batteries can cause property damage, injury, or burns if a conductive material, such as jewelry or keys, touches exposed terminals. The material may complete an electrical circuit and become extremely hot. To protect against such unwanted current drain, exercise care in handling any charged battery, particularly when placing it inside your pocket, purse, or other container with metal objects.

Do not disassemble the SHOUT ts for battery replacement. Return it to NAL Research for services. Risk of explosion if battery is replaced with an incorrect type. Dispose of the batteries (ts) according to local, state, and federal regulations or laws.